


## Back Panel




- Connect the +V to the USB charger using the USB mini cable
- CHRG – Lit when charging
- STAT – Relative battery level. When dim recharge batteries
- 95% Charge can be reached in 6 hours
- Run time is 11 to 12 hours

## Operating Instructions

- Connect the music source into the far left connector on the front panel
- If using USB and the source does not recognize the USB Codec:
  - Disconnect the USB source cable
  - Reconnect the USB source cable
  - Wait 15 seconds
  - Swan Song Audio has tested a variety of USB sources but cannot guarantee compatibility with all USB sources
- Rotate the VOL thumbwheel to the left to turn down the volume
- Place the far right ON switch on the front panel into the UP position. Down if charging with USB charge block (back USB)
- Connect the headphones or other 3.5mm phone cable into the 3.5mm OUT jack next to the music source connector
- Set the music source volume to maximum
- Start the music on the music source
- Rotate the VOL thumbwheel to the desired level. Swan Song Audio is not responsible for damage caused by excessive volume levels
- Audio is upsampled to 24 bit 96kHz

## Front Panel



- IN – The following IN connector options are supported
  - USB mini
  - TOSLINK
- OUT – 3.5mm Stereo
- VOLUME – Turn Thumbwheel right to increase
- ON – Up to listen Down (CHRG) to charge
- Use with headphone loads 22 to 600 ohms
- Electrostatic headphones are not supported

## Cautions Warranty

- Do not expose the DAC / amplifier to liquids or to temperature extremes as deemed by Swan Song Audio
- Electromagnetic interference will affect the performance
- Only headphone loads from 22 to 600 ohms are supported
- Electrostatic headphones are not supported
- Do not charge with more than 5 volts DC via USB
- Clean metal with “Windex” and a micro cloth
- The warranty period is 1 year from the date of purchase for manufacturing defects and not for wear and tear caused by usage or negligence, as deemed by Swan Song Audio
- Opening is only permitted to change the battery back using the instructions supplied with the battery
- Follow all LION Battery precautions
- Violating the cautions voids the warranty
- The unit can only be serviced by directly or with instructions from Swan Song Audio
- Contact Swan Song Audio for service or any warranty questions
- Repairs deemed by Swan Song Audio as outside the warranty will be handled by Swan Song Audio at the owners expense

